

# FE060-60C-EM

FlexPro® Series

**Product Status:** Active

### **SPECIFICATIONS**

Current Continuous


DC Supply Voltage

Network Communication

60 A

10 - 55 VDC

EtherCAT



The **FE060-60C-EM** is a FlexPro® series servo drive with IMPACT™ architecture.

The **FE060-60C-EM** offers full tuning control of all servo loops and is designed to drive brushed and brushless servo motors, and closed loop stepper motors. The drive accepts a variety of external command signals, or can use the built-in Motion Engine, an internal motion controller used with Sequencing and Indexing commands. Programmable digital and analog I/O are included to enhance interfacing with external controllers and devices.

The **FE060-60C-EM** features an EtherCAT® interface for network communication using CANopen over EtherCAT (CoE) and USB connectivity for drive configuration and setup. All drive and motor parameters are stored in non-volatile memory.

IMPACT<sup>TM</sup> (Integrated Motion Platform And Control Technology combines exceptional processing capability and high-current components to create powerful, compact, feature-loaded servo solutions. IMPACT<sup>TM</sup> is used in all FlexPro<sup>®</sup> drives and is available in custom products as well.


#### **FEATURES**

- CoE Based on DSP-402 Device Profile for Drives and Motion Control
- Synchronization using Distributed Clocks
- Position Cycle Times down to 100μs
- Four Quadrant Regenerative Operation
- Programmable Gain Settings
- PIDF Velocity Loop

- Compact Size, High Power Density
- On-the-Fly Mode Switching
- On-the-Fly Gain Set Switching
- Dedicated Safe Torque Off (STO) Inputs
- Space Vector Modulation (SVM) Technology

Feedback Supported	• Incremental Encoder	Motors Supported	<ul><li> Three Phase</li><li> Single Phase</li><li> Stepper</li></ul>	Modes of Operation	<ul> <li>Profile Modes</li> <li>Cyclic Synchronous Modes</li> <li>Current</li> <li>Velocity</li> <li>Position</li> </ul>
Command Sources	• Indexing	Inputs / Outputs	<ul> <li>4 Programmable Digital Inputs</li> <li>3 Programmable Digital Outputs</li> <li>1 Programmable Analog Input</li> </ul>	Agency Approvals	<ul><li>RoHS</li><li>UL (Pending)</li><li>CE (Pending)</li><li>TUV Rheinland (STO) (Pending)</li></ul>





## **INFORMATION ON APPROVALS AND COMPLIANCES**



The RoHS Directive restricts the use of certain substances including lead, mercury, cadmium, hexavalent chromium and halogenated flame retardants PBB and PBDE in electronic equipment.



SPECIFICATIONS						
Electrical Specifications						
Description	Units	Value				
Nominal DC Supply Input Range	VDC	12 – 48				
DC Supply Input Range	VDC	10 – 55				
DC Supply Undervoltage	VDC	8				
DC Supply Overvoltage	VDC	58				
Logic Supply Input Range (required)	VDC	10 – 55				
Safe Torque Off Voltage (Default)	VDC	5				
Minimum Required External Bus Capacitance	μF	500				
Maximum Continuous Current Output <sup>1</sup>	A (Arms)	60 (60)				
Efficiency at Rated Power	%	99				
Maximum Continuous Output Power	W	3267				
Maximum Power Dissipation at Rated Power	W	33				
Minimum Load Inductance (line-to-line) <sup>2</sup>	μН	150 (@ 48VDC supply); 75 (@24VDC supply); 40 (@12VDC supply)				
Switching Frequency	kHz	20				
Maximum Output PWM Duty Cycle	%	83				
maximem ediperi mi Berly eyere		l Specifications				
Description	Units	Value				
Communication Interfaces <sup>3</sup>	-	EtherCAT® (USB for configuration)				
Command Sources	_	±10 V Analog, Over the Network, Sequencing, Indexing, Jogging, Step				
Communa 300ices		& Direction, Encoder Following				
Feedback Supported		Absolute Encoder (BiSS C-Mode, EnDat 2.2), Hall Sensors, Incremental				
тееараск зорронеа		Encoder, Auxiliary Incremental Encoder, Tachometer (±10V)				
Commutation Methods	-	Sinusoidal, Trapezoidal				
Modes of Operation	-	Profile Modes, Cyclic Synchronous Modes, Current, Velocity, Position				
Motors Supported <sup>4</sup>	_	Three Phase (Brushless Servo), Single Phase (Brushed Servo, Voice Coil,				
		Inductive Load), Stepper (2- or 3-Phase Closed Loop)				
Hardware Protection		40+ Configurable Functions, Over Current, Over Temperature (Drive & Motor), Over Voltage, Short Circuit (Phase-Phase & Phase-Ground),				
naraware Profection	-	Under Voltage				
Programmable Digital Inputs/Outputs	<del>-</del>	4/3				
Programmable Analog Inputs/Outputs		1/0				
Primary I/O Logic Level	-	5 VDC, not isolated				
Current Loop Sample Time	μS	50				
Velocity Loop Sample Time		100				
Position Loop Sample Time	μS	100				
	μs MHz					
		20 (5 pre-quadrature)				
Mechanical Specifications           Description         Units         Value						
Size (H x W x D)	mm (in)	38.1 x 25.4 x 16.0 (1.50 x 1.00 x 0.61)				
Weight	g (oz)	22.7 (0.8)				
Ambient Operating Temperature Range <sup>5</sup>	°C (°F)	0 - 65 (32 - 149)				
Storage Temperature Range	°C (°F)   -40 – 85 (-40 – 185)					
Relative Humidity	-	0-95%, non-condensing				
Form Factor	-	PCB Mounted				
P1 SIGNAL CONNECTOR*	<del> </del> -	80-pin 0.4mm spaced connector				
TERMINAL PINS	<del> </del> -	26x Terminal Pins				
		==				

### Notes

- Continuous A<sub>rms</sub> value attainable when RMS Charge-Based Limiting is used.
   Lower inductance is acceptable for bus voltages well below maximum. Use external inductance to meet requirements.
   EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- 4. Maximum motor speed for stepper motors is 600 RPM. Consult the hardware installation manual for 2-phase stepper wiring configuration. Additional cooling and/or heatsink may be required to achieve rated performance. Repeated over temperature events may cause damage to the drive due to the drive's high power density. Ensure that proper thermal management is adhered to during drive operation.

### \*Mating Connector Kit

Surface mount board connector for P1 and board spacers can be ordered as a kit using ADVANCED Motion Controls' part number KC-MC1XFE01.



in 1 3 5 7 9 1 3 5 7 7 7	Name GROUND PAI-1+ PAI-1- THERMISTOR GROUND ENC 1 DATA+ / A+ ENC 1 DATA- / A-	Description / Notes Ground Differential Programmable Analog Input or Reference Signal Input (12-bit Resolution) Motor Thermal Protection.	P1 – Signal I/O GND I	Pin 2 4	Name GROUND	Description / Notes Ground	J/C GN
3 5 7 9 1 3 5	PAI-1+ PAI-1- THERMISTOR GROUND ENC 1 DATA+ / A+	Differential Programmable Analog Input or Reference Signal Input (12-bit Resolution)					
5 7 9 1 3 5	PAI-1- THERMISTOR GROUND ENC 1 DATA+ / A+	Reference Signal Input (12-bit Resolution)		1			
7 9 1 3 5	THERMISTOR GROUND ENC 1 DATA+ / A+			7	DATA+ USB	USB Data Channel	1/
9 1 3 5	GROUND ENC 1 DATA+ / A+	Motor Thermal Protection.	!	6	DATA- USB	USB Data Charinei	1/
1 3 5	ENC 1 DATA+ / A+		1	8	GROUND	Ground	G
1 3 5		Ground	GND	10	SCLA	I <sup>2</sup> C Data Signals for Addressing, Network	
3 5			_			Error LED, and Bridge Status LED. See	$\vdash$
5	ENC 1 DATA- / A-	Differential Data Line for Absolute Encoders	1/0	12	SDAA	Hardware Manual for more info.	1/
5	LINC I DATA	(BiSS: SLO+/-) or Differential Incremental	1/0	14	HALL A		
$\rightarrow$		Encoder A.	_				$\vdash$
7	ENC 1 CLK+ / B+	Differential Clock Line for Absolute Encoders (BiSS: MA+/-) or Differential	1/0	16	HALL B	Single-ended Commutation Sensor Inputs	
	ENC 1 CLK- / B-	Incremental Encoder B.	1/0	18	HALL C		
9	GROUND			20	GROUND	Cround	
9	GROUND	Ground	GND	20	GROUND	Ground	G
1	ENC 1 REF+ / I+	Differential Reference Mark for Absolute		22	ENC 2 A+		
-	•	Encoders (Leave open for BiSS) or	$\vdash$	-		Differential Incremental Encoder A.	-
3	ENC 1 REF- / I-	Differential Incremental Encoder Index.	1 1 1	24	ENC 2 A-		
	DECEDI (ED				ENO O D		
5	RESERVED	Reserved. Do not connect.	-	26	ENC 2 B+	Differential Incremental Encoder B.	
7	RESERVED	Reserved. Do not connect.	-	28	ENC 2 B-		₩
9	RESERVED	Reserved. Do not connect.	-	30	ENC 2 I+	Differential Incremental Encoder Index.	
1	PDI-1	Programmable Digital Input	I	32	ENC 2 I-	Billererinar incremental Encoder index.	
3	PDI-2	Programmable Digital Input		34	PDO-1	Programmable Digital Output (TTL/8mA)	
5	PDI-3	Programmable Digital Input	1	36	PDO-2	Programmable Digital Output (TTL/8mA)	
7	PDI-4	Programmable Digital Input	1	38	PDO-3	Programmable Digital Output (TTL/8mA)	
9	GROUND	Ground	GND	40	GROUND	Ground	(
1	TX- IN			42	TX- OUT		
3	TX+ IN	Transmit Line IN (100 Base TX)		44	TX+ OUT	Transmit Line OUT (100 Base TX)	
5	RX- IN		<del>                                     </del>	46	RX- OUT		
7	RX+ IN	Receive Line IN (100 Base TX)	<del></del>	48	RX+ OUT	Receive Line OUT (100 Base TX)	-
		- 0)/ O	0			0\/ 0	
9	+3V BIAS IN	+3V Supply for Transformer/Magnetics Bias		50	+3V BIAS OUT	+3V Supply for Transformer/Magnetics Bias	-
.		Link and Activity Indicator for IN port.				Link and Activity Indicator for OUT port.	١.
1	LINK/ACT IN	Function based on protocol specification.	1/0	52	LINK/ACT OUT	Function based on protocol specification.	I
_		See Hardware Information below.				See Hardware Information below.	₩
		Run State Indicator for Network. Function					
3	STATUS	based on protocol specification. See	1/0	54	RESERVED	Reserved. Do not connect.	
		Hardware Information below.					
5	RESERVED	Reserved. Do not connect.	-	56	RESERVED	Reserved. Do not connect.	
7	RESERVED	Reserved. Do not connect.	-	58	RESERVED	Reserved. Do not connect.	
9	GROUND	Ground	GND	60	GROUND	Ground	0
1	RESERVED	Reserved. Do not connect.	-	62	RESERVED	Reserved. Do not connect.	
3	RESERVED	Reserved. Do not connect.	-	64	RESERVED	Reserved. Do not connect.	
5	RESERVED	Reserved. Do not connect.	-	66	RESERVED	Reserved. Do not connect.	$\vdash$
7	RESERVED	Reserved. Do not connect.	-	68	STEP	Step Input.	-
9	RESERVED	Reserved. Do not connect.	-	70	DIR	Direction Input.	+
			-	70	RESERVED	Reserved. Do not connect.	$\vdash$
1	RESERVED	Reserved. Do not connect.		/2	KESEK V ED	keserved, Do not connect.	-
3	+5V	+5VDC unprotected supply for local logic		74	RESERVED	Reserved. Do not connect.	
		(See Note 1)			-		-
5	+5V_USER	+5VDC User Supply for feedback or	0	76	+3V3	+3.3VDC supply for local logic signals	
7	+5V_USER	external devices (See Note 1)	0	78	+3V3	(100 mA max)	
·	GROUND	Ground	GND	80	GROUND	Ground	(
Conr	nector Information	80-pin, 0.4mm spaced connector		• • • • • • • • • • • • • • • • • • •	+3V +3V3 GROUND 8		A+ U
Mating Connector Details PAI		PANASONIC: P/N AXT380224					
Mating Connector No		• ::*	2	GROUND 7 +5V USER +5V USE	9   1 Gf	1+	


Notes 1.

1. Total current through pins P1-73/75/77 should not exceed 300mA, while no single pin should be loaded more than 150mA.



### **TERMINAL PIN LOCATIONS**

The 26 Terminal Pins provide connection to the high power drive signals. Terminal Pins must be soldered to an interface board.



Pin	Name	Description / Notes	I/O
T1	STO-1 INPUT	Safe Torque Off – Input 1	
T2	STO RETURN	Safe Torque Off Return	STORET
T3	STO-2 INPUT	Safe Torque Off – Input 2	I
T4	LOGIC PWR	Logic Supply Input (10 - 55VDC) (required)	1
T5	HV		I
T6	HV	DC Supply Input (10-55VDC). Minimum 500μF external capacitance required between HV and POWER GND.	
T7	HV		
T8	HV		
T9	HV		I
T10	MOTOR C		0
T11	MOTOR C	Motor Phase C. All provided motor phase output pins must be used.	
T12	MOTOR C		
T13	MOTOR C		
T14	POWER GND	Ground.	GND
T15	MOTOR B		
T16	MOTOR B	Motor Phase B. All provided motor phase output pins must be used.	0
T17	MOTOR B	Motor Fridse B. All provided motor phase output plits most be used.	0
T18	MOTOR B		0
T19	POWER GND		GND
T20	POWER GND	Cround	GND
T21	POWER GND	Ground.	
T22	POWER GND		GND
T23	MOTOR A		0
T24	MOTOR A	Motor Phase A. All provided motor phase output pins must be used.	
T25	MOTOR A		
T26	MOTOR A		0

### **Terminal Pin Details**

#### Safe Torque Off (STO) Inputs

The Safe Torque Off (STO) inputs are dedicated +5VDC sinking single-ended inputs. For applications not using STO functionality, disabling of the STO feature is required for proper drive operation. STO may be disabled by following the STO Disable wiring instructions as given in the hardware installation manual. Consult the hardware installation manual for more information.




### HARDWARE INFORMATION

### **LED Functionality**

LINK/ACT IN (P1-51); LINK/ACT OUT (P1-52); STATUS (P1-53);


The LINK/ACT IN, LINK/ACT OUT, and STATUS pins serve as EtherCAT network indicators. On a standard RJ-45 connector used with EtherCAT network topology, the typical EtherCAT network indicator LED locations are as shown in the below diagrams. Note that the drive features signals for connection to LEDs on an RJ-45 connector, but the connector itself is not included on the drive. The Development Card assembly FD060-60C-EM features a built-in RJ-45 connector with LEDs for this purpose.



LINK/ACT IN and LINK/ACT OUT are used to drive the corresponding LINK IN and LINK OUT LEDs on a typical RJ-45 connector. The STATUS pin is used to drive the Status LED. The ERROR LED is driven by the I<sup>2</sup>C Data signals (P1-10/12). Consult the hardware installation manual for recommended wiring connections. The LED Function Protocol tables below describe typical LED functionality.

LINK/ACT LEDS						
LED State	Description					
Green – On	Valid Link -	No Activity				
Green – Flickering	Valid Link - Network Activity					
Off	Invalid Link					
	STATUS LED					
LED State	LED State Description					
Green – On	The device is in the	state OPERATIONAL				
Green – Blinking (2.5Hz – 200ms on and 200ms off)	The device is in the state PRE-OPERATIONAL					
Green – Single Flash (200ms flash followed by 1000ms off)	The device is in state SAFE-OPERATIONAL					
Green – Flickering (10Hz – 50ms on and 50ms off)	The device is in sto	not yet entered the INIT state, or ate BOOTSTRAP, or operation in progress				
Off	The device is in state INIT					
ERROR LED						
LED State	Description	Example				
Red – On	A PDI Watchdog timeout has occurred.	Application controller is not responding anymore.				
Red – Blinking (2.5Hz – 200ms on and 200ms off)	General Configuration Error.	State change commanded by master is impossible due to register or object settings.				
Red – Flickering (10Hz – 50ms on and 50ms off)  Booting Error was detected. INIT state reached, but parameter "Change" in the AL status register is set to 0x01:change/error		Checksum Error in Flash Memory.				
Red – Single Flash (200ms flash followed by 1000ms off)	The slave device application has changed the EtherCAT state autonomously: Parameter "Change" in the AL status register is set to 0x01:change/error.	Synchronization error; device enters SAFE- OPERATIONAL automatically				
Red – Double Flash (Two 200ms flashes separated by 200ms off, followed by 1000ms off)  An application Watchdog timeout has occurred.		Sync Manager Watchdog timeout.				







#### PART NUMBERING AND CUSTOMIZATION INFORMATION E 060-60C-E M F **Feedback Drive Series** FlexPro® Multi Encoder (BiSS, 5V Incremental) Environment **Network Communication** EXtended Environment Ε **E**therCAT С CANopen Form Factor R RS485/232 FlexPro® Embedded ΙP Ethernet/IP FlexPro® E (W/ Development board) D **Continuous Current** FlexPro® Machine Mount 5 **5**A Maximum DC Bus Voltage 10 10A 060 60 VDC **25**A 25 100 100 VDC 50 60C 60A (continuous only, no peak)

ADVANCED Motion Controls also has the capability to promptly develop and deliver specified products for OEMs with volume requests. Our Applications and Engineering Departments will work closely with your design team through all stages of development in order to provide the best servo drive solution for your system. Equipped with on-site manufacturing for quick-turn customs capabilities, ADVANCED Motion Controls utilizes our years of engineering and manufacturing expertise to decrease your costs and time-to-market while increasing system quality and reliability.

#### **Examples of Customized Products**

- Optimized Footprint
- ▲ Private Label Software
- ▲ OEM Specified Connectors
- No Outer Case
- ▲ Increased Current Resolution
- ✓ Increased Temperature Range
- Integrated System I/O

- Tailored Project File
- Silkscreen Branding
- Optimized Base Plate
- ▲ Increased Current Limits
- ▲ Conformal Coating
- Multi-Axis Configurations
- ▲ Reduced Profile Size and Weight

Feel free to contact us for further information and details!

#### **Available Accessories**

ADVANCED Motion Controls offers a variety of accessories designed to facilitate drive integration into a servo system. Visit <a href="https://www.a-m-c.com">www.a-m-c.com</a> to see which accessories will assist with your application design and implementation.

### **Development Board**

The FE060-60C-EM is offered in a pre-soldered development board assembly to provide easy connections to motor, power, and signal functions. The development board assembly can be ordered as model number **FD060-60C-EM**.



All specifications in this document are subject to change without written notice. Actual product may differ from pictures provided in this document.